U(OVO

Appearance



To turn on device: Hold power button until the device switches on. To turn off device: Hold power button during operation until the device shows a menu, select "Power off".

To turn off display: Press the power button .Device also turn off the display automatically if left idle for some time. That amount of time can be configure at "Setting→Display→Sleep"

To turn on the display: Press the power button lightly .



◆ Volume Button

Scan Button

Scanner

Micro USB Port

19 POGO Pin

TF Slot

Micro SIM Slot

PSAM Slot

Battery Installation

Insert battery in the direction as shown in the picture on the right .Sit the battery tightly in the corresponding position.





Note: Gently rotate the battery cover clip in quarter-turn motion.Do not



Battery Operation

Charge the device and battery with only Urovo accessories.

Do not short the battery

Do not store battery in hot, humid, or corrosive environment. Do not break or crack open the battery.

Do not store battery when it is fully charged completely drained. If device is not used for long period of time, remove the battery from the



Note

- 1.If battery is misshapen, or is found leaking, replace the battery
- 2. The battery should be charged for at least 8 hours before the first use. 3.Do not leave the battery charging unattended for long hours, especially after the battery is fully charged.

SIM/TF Cards Installation



1. Swing open the main battery cover clip by 90 degrees, you can then remove the battery cover 2. Insert the SIM card or microSD/TF card into their corresponding slots in the battery compartment

Note:You should gently push the SIM/TF card to the correct position without using excessive



Battery Charging Instruction



DC Power Adapter

Charging by DC Power Adapter

When device is charged using DC power adapter ,the power indication LED is red, when fully charged, the LED will turn green



USB Data Communication Cable

Charging by USB Data Communication Cable Connect the device and computer by USB data communication cable.



When starts to charge battery, the P indication LED of dock will be green. The red C indication LED will turn green after battery is fully charged.



Connecting To PC

After you installed the android driver or an android smartphone assistant, you can connect the device to your PC with the USB cable provided. (You can download the softwares mentioned above from www.urovo.com/en. After the device connected to your PC, the screen would display like this:



After the device connected to your PC, you could drag the top show the USB options.



enable / disable USB debugging

Select this option to enable / disable device as USB storage to the ${\operatorname{PC}}$



Check this to enable USB debugging.



as a USB storage to PC.

Note: When you enable device as USB storage to PC, the flash memory of the device is mapped as a PC drive. At this point of time, you cannot download software or program. If you wish to download software or program the device, switch it charging mode.







Power Button

-8 User-defined

Scan Button

Loudspeaker Battery Cover Clip

-18 Rear Camera

2