Interleaved 2 of 5

Enable Interleaved 2 of 5

Disable Interleaved 2 of 5

Industrial 25

Enable Industrial 25

Disable Industrial 25

Standard 25

Enable Standard 25

Disable Standard 25

Code 39

Enable Code 39

Disable Code 39

Full ASCII on

Full ASCII off

Codabar

Enable Codabar

Disable Codabar

Code 93

Enable Code 93

Disable Code 93

2D PDF417

Enable PDF417

Disable PDF417

2D Data Matrix

Enable Data Matrix

Disable Data Matrix

Enable Rectangular

Disable Rectangular

Enable DM

Enable Image DM

Enable Both

2D QR Code

Disable QR Code

Enable Micro QR

Disable Micro QR

Enable Image Micro QR

Enable Image Micro QR

Data Code

0

1

2

3

4

5

6

7

8

9

A

B

C

D

E

F

save or Cancel

Save

Cancel a previous read data

Cancel previous a bunch of data

RSS-14

Enable RSS-14

Disable RSS-14

RSS-Limited

Enable RSS-Limited

Disable RSS-Limited

RSS-Expand

Enable RSS-Expand

Disable RSS-Expand

2D Barcode Scanner User Manual

Output Setting Character

Return to Factory Default

Speaker

Mute On

Mute Off

Decoding Prompt

Output Decoding Prompt

Without Decoding Prompt

Light

Normal

No Light

Always Light

Caps Lock

Caps Lock Off

Caps Lock On

Interfaces

USB DATAPIPE

USB HID-KBW

KBW

USB COM Port Emulation

HID-POS

Reading Mode

Manual

Continuous Mode

Auto-scan Mode

Trigger Mode

Keyboard Language

USA

FRANCE

UK

Baud Rate

9600

115200

Cpas Lock

No Conversion

To Lowercase

To Uppercase

Prefix

Enable Adding Prefix

Disable Adding Prefix

Visible Code ID

Ending Suffix

Disable Adding Ending Suffix

Enable CR Suffix

Enable CRLF Suffix

Enable TAB Suffix

Normal and Inverse Data

Enable Normal and Inverse Data

Disable Normal and Inverse Data

CODE 128

Enable

Disable

EAN-8

Enable EAN-8

Disable EAN-8

Convert to EAN-13

No Convert to EAN-13

EAN-13

Enable EAN-13

Disable EAN-13

UPC-E

Enable UPC-E

Disable UPC-E

Convert \to UPC-A

No Convert to UPC-A

UPC-A

Enable UPC-A

Disable UPC-A

Transmit system character 0

No Transmit system character 0